

## Bluetooth PIN Input Numbers



0



1



2



3



4



5



6



7



8



9



Enter

## Bluetooth



Unpair



Bluetooth HID Profile



Save Configuration

## Tones



Low Frequency



\*Medium Frequency



High Frequency



\*Do Not Mute Beeper



Mute Beeper

## Scan Prefix



<PREFIX> <DATA >



Scan Prefix



\*Data As Is

## Number Input



0



1



2



3



4



5



6



7



8



9

## Code Types



Enable All Code Types

## System



Clear Data



Reset Factory Defaults